




# AIRDOPES PLUS 311

## SMART GUIDE


### PACKAGE CONTENTS



S L



### PRODUCT LABELLING



CTC (CAPACITIVE TOUCH CONTROL)




### POWER ON/OFF




Insta Wake N'Pair (IWP™)



### BLUETOOTH PAIRING



1



2


Choose "Airdopes Plus 311" to Connect



### FUNCTIONS (CALL/MUSIC)

- Tap Once
- Tap Twice
- L Left Earbud
- R Right Earbud

#### TOUCH FUNCTIONS



Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.



### FUNCTIONS (VOICE ASSISTANT/ BEAST™ MODE)

- Long Touch (3s)
- L Left Earbud
- R Right Earbud



ACTIVATE GOOGLE VOICE ASSISTANT/SIRI



ACTIVATE/ DEACTIVATE GAMING BEAST™ MODE


**Voice Assistant:** Long touch the CTC on the left earbud for 3 seconds to activate the default smart voice assistant (Google Voice Assistant/Siri).  
**BEAST™ Mode:** Long touch the CTC on the right earbud for 3 seconds to activate BEAST™ mode. Long touch the CTC on the right earbud for 3 seconds again to de-activate BEAST™ mode.

Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.



### RESET AIRDOPES

#### FORGET DEVICE




LONG TOUCH THE CTC ON BOTH EARBUDS FOR 5 SECONDS



CTC (CAPACITIVE TOUCH CONTROL)

#### OPEN CASE & PERFORM FRESH CONNECTION



### LED STATUS GUIDE

<20% : WHITE LED BLINKS RAPIDLY

LOW BATTERY

21-99% : WHITE LED FLASHES SLOWLY

CHARGING

100% : SOLID WHITE LED

FULLY CHARGED

<20% : RED LED BLINKS 3 TIMES EVERY 30 SECONDS

LOW BATTERY

21-99% : SOLID RED LED

CHARGING

100% : SOLID BLUE LED FLASHES FOR 10 SECONDS & THEN TURNS OFF

FULLY CHARGED

### SPECIFICATIONS

Headphone Type	TWS
Bluetooth Version	5.3
Music Playtime	Up to 50 hours (at 60% volume)
Number of ENx™ Equipped Mics	2
IWP™ Tech	Yes
BEAST™ Mode	Yes; 50 ms Low Latency
Transmission Range	10 m
Driver Size	10 mm*2
Supported Codec	AAC/SBC
Frequency	20 Hz-20 kHz
Battery	470 mAh (Case); 40 mAh*2 (Earbuds)
ASAP™ Charge	Yes; 10 mins charge = 150 mins playtime
Charging Time	30 mins (Earbuds); 1.5 hours (Case)
Charging Interface	USB Type-C
Water Resistance	IPX4



### CHARGING GUIDELINES

#### Charging norms & Precautionary Guidelines: -

- 1) Charger/Brick/Adapter : 5V/2A
- 2) Cable/Wire : Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.



USB-C PORT

Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them. (2) Please note that the earbuds cannot be used / switched on while charging.



### LEARN MORE ABOUT YOUR PRODUCT



Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information

