




AAVANTE BAR 590

RAISE THE BAR



USER MANUAL



AUX/USB MODES

1. Turn on the soundbar and switch it to the desired mode
2. Connect the respective mode (AUX/USB) and start the playback

CHARGING

- Connect one end of the provided charging cable to the charging input and the other end to a standard 5V/2A wall adaptor
- While getting charged, the LED stays red
- Once the speaker gets fully charged, the LED turns off

Thank you for purchasing the Aavante Bar 590. You are now just a step away from the realm of audio bliss. Please follow this user manual carefully in case of any doubt that may arise. You can stay plugged into the sound via Bluetooth wireless technology, USB and AUX modes. This portable soundbar has been designed for smooth interface that requires minimal of efforts. Let's seize the day with an awesome sound!

Package Contains:

- 1x Wireless Soundbar
- 1x User Manual
- 1x USB Type C Charging Cable
- 1x Warranty Card
- 1x Audio Cable
- 1x Catalogue


SPECIFICATIONS

Speaker Type	Portable Soundbar
Bluetooth Version:	V5.0
Net Weight:	0.7kg
Working Range:	10m
Driver Size:	50mm*2
Supported Profiles:	A2DP, AVRCP, HFP
Frequency:	82Hz-20kHz
Input Voltage:	DC 5V/2A
Output Power:	25W RMS
Charging Time:	About 4 hours
Charging Interface	USB Type C
Playing Time:	Up to 6HRS (at 60% volume)
Battery:	2500mAh



PRODUCT OVERVIEW

SOUNDBAR CONTROL PANEL:



- 1 - Volume Decrease/Previous Track
- 2 - Play/Pause
- 3 - Volume Increase/Next Track
- 4 - Power/Mode Button
- 5 - Mode Indicator
- 6 - Charging Indicator

Power Button	Long press the Power / Mode button to turn the soundbar on / off.
'-' Button	Short press in steps to decrease the volume in any mode. Long press in USB/ Bluetooth modes to return to previous song.
'+' Button	Short press in steps to increase the volume in any mode. Long press in USB/Bluetooth modes to skip to next song.
Play/Pause button	Single press to play/pause tracks in any mode. Long press to disconnect existing BT connection and start searching for new one.

SAFETY PRECAUTIONS

- Please note that the battery life of the soundbar varies with the volume music is being played at. If at a lower volume, the battery life will be longer than when the speakers are playing at full volume
- If the speaker requires cleaning, please ensure that it is done with the utmost of care. Furthermore, make sure it is turned off and disconnected from all Bluetooth devices. Do not use alcohol, benzene and other chemicals to clean the speaker. Instead, use only a soft cloth. Do not allow the speaker within range of extremely hot or cold substances.
- Try to ensure that no physical damage comes to the speaker via falling, or coming into contact with hard surfaces or sharp edges.
- Do not dismantle the speaker or handle the battery in any way. If any issue arises with the speaker, please enlist the aid of a manufacturer. The battery must not be mishandled or replaced as it can result in explosions or fire hazards. Therefore, please ensure that any servicing of the speaker is done through the service provider or manufacturer.
- If the speaker gets wet, please ensure that it is dried quickly and completely after coming into contact with water. Please do not allow the speaker to get wet at any cost.

Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter	: 5V 2A
2) Cable/Wire	: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Mode Button	Single press the Mode / Power button to switch among Bluetooth, USB or AUX modes.
Mode Indicator LED (left)	Mode indications are as follows; Bluetooth mode in blue LED, USB mode in purple LED and AUX mode in red LED.
Charging Indicator LED (right)	During charging the red LED gets lit, whereas once the charge gets complete it gets indicated by the LED getting turned off.

BLUETOOTH PAIRING

1. Turn the soundbar on. (By default, Bluetooth mode gets switched on)
2. Activate your media device's Bluetooth functionality and search for "Aavante Bar 590". As soon as it gets selected by you and paired, music can be played wirelessly.

Note:

- The soundbar can automatically reconnect to the last paired device whenever switched on in BT mode.

