


ACWVO®



mini soundbar

CARNIVAL Desi

Manual



Buttons:

- Short press "M": Change EQ modes, Bluetooth, FM, USB, TF .
- "+": Volume up/Next track
- "-": Volume down/Previous track
- "▶||": Play/Pause, Answer/Hang up phone call, TWS

Function:

Bluetooth Connection:

- When turning on the Bluetooth speaker, it will be in Bluetooth mode at first. Open your Bluetooth device and search for "ACwO CARNIwAL DESI" to connect. Once this speaker is paired to your device, it will connect to your device automatically next time if you do not delete the Bluetooth memory on your device.

Music Play:

- Insert USB drive or micro-SD card with MP3 files to enjoy music.
- Use the 3.5mm audio cable to connect your phone with the speaker to play music.
- Short press "+" to play the next song.
- Long press "+" to increase the volume.
- Short press "-" to play the previous song.
- Long press "-" to reduce the volume.

● Radio Mode:

Insert the charging cable into the slot to act as an external antenna to enhance the signal. Press the "M" button to enter FM mode. Long press the "⏮" button to search channels automatically. After the searching is completed, press +/- to switch the radio.

● Switch between Sound Modes:

Once your soundbar is powered on, simply press the "M" button twice to switch between different sound modes: Cinematic, Party and Rock. Tailor your audio experience to match your mood or the music you're playing. Activate Voice Assistance.

● Voice Assistance:

To activate the feature, press the "M" button three times and access your preferred voice assistance to enjoy audio the way you like it.

● How to Connect Two CARNIwAL Soundbars:

1) Power On

Switch on both CARNIwAL soundbars.

2) Pair the Soundbars Together

Press and hold the Play/Pause button on one of the soundbars for 5 seconds. The two soundbars will automatically pair and connect with each other.

3) Connect to Your Device

Using Bluetooth, connect the soundbar to your phone, tablet, or other device.

4) Enjoy Synchronized Sound

That's it! Both soundbars will now play the same audio together, delivering a powerful, immersive sound experience.

● Charging:

- Use the Type-C charging cable.
- When the speaker is charging, the red light will be on; the lights will turn off when it's fully charged.
- Repeated charging and discharging will lead to a decline in battery life, which is a normal phenomenon for all rechargeable batteries.

● Calling:

- Click the "▶||" button to answer or hang up the phone call.
- Long press the "▶||" button to reject the phone call.

● Notice:

- Use the product for its intended purpose only.
- Please store and use this product at room temperature.
- Do not expose this product to rain or wet conditions.
- Do not drop the product to avoid damage.
- Do not disassemble or repair the product by yourself.
- This product has a built-in lithium battery — do not discard it casually or put it in fire, as it may cause danger.