

Thank you for choosing the boAt Rockerz 450. This manual is meant to guide you through to the shores of Nirvana without too much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we





Introduction

Attachment List

Headphone x 1 Charging Cable x1



Structure Introduction





Technical Specifications

- Bluetooth Version: Bluetooth v4.2 Support: A2DP. VARCP HEP HSPV
- Wireless working distance: 10M
- Sensitivity: -80dB<+0.1%BER
- Frequency Range: 2.4GHz-2.480GHz Music time: 8 Hours
- Talk time: 8 Hours
- Standby time: 300-400 Hours
- Charging hours: USB DC5V.
- Charging: 3.5 hours to 4.5 hours
- Charging Electric Current: 210mA

Button Functions

Power on: Press and half the button for 3 seconds to turn the headphones on. There will be a prompt and the LED light will flash red and blue alternately, indicating that the headph has are ready for pairing Play/pause: Press the button to play/pause music as per your conve + nce Volume up: Tap the button to increase the volume to your preferred - el. Volume down: Tap the button to decrease the volume to your preferi - level. Next Track: Press and hold to button to play the previous track. Previous Track: Press and hold the button to play the next track. Answer a call: Tap the button to answer any incoming calls throug \ e headphones. To end a call: Tap the button to end an active call. Reject call: Double tap the button to reject an incoming call Power off: Press and hold the button for 3 seconds

to turn the headphones off. There will be a prompt and



To Pair (Bluetooth)

- 1. Press and hold the the power button to switch the speakers on, there will be a prompt as well as the rapid blinking of the aforementioned LED indicator light. Turn on the Bluetooth function on your Smartphone or any
- Bluetooth devices and connect the two. will switch off. 3. Enter the passkey '0000' if one is asked for during
- 4. After successfully pairing, the speaker is now ready to play music from your Smartphone.
- 5. The speaker will not automatically connect to this Safety Precautions device when switched on if it is in range and the

You can use headphones as a wired headphone to save battery. Simply connect one end of the 3.5mm AUX cab to the bottom of the ear cushion and the other end to

Charging the Headset

- 1. Use the Micro USB cable provided to charge the boAt Rockerz 450. Insert the micro cable end into the speaker and the USB port into a charging adapter or any other charging device.
- 2. A red light will indicate the speakers have begun to charge. Once charging has been completed, the LED ligh
- 3. Please do not keep disconnecting and reconnecting

1. Do not use headphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing headphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens. Therefore, please avoid wearing your headphones while driving.

2. To avoid damage to your hearing, make sure that the

volume on your music player is at an appropriate level

gradually lead to a loss of hearing. Therefore, listening sessions that are at higher volumes should not be for too long. If you are planning to use the headphones for extended periods of time, it is safer to keep the volume at a low level.

- 3. If the speaker requires cleaning please ensure that it is done with the utmost of care. Further, make sure it is turned off and disconnected from all Bluetooth devices. Do not use alcohol, benzene and other chemicals to clean the speaker. Do not allow the speaker within range of extremely hot or cold substances.
- 4. Do not dismantle the speaker or handle the battery in any way. If any issue arises with the speaker, please enlist the aid of a manufacturer. The battery must not be mishandled or replaced as when it can result in explosions or fire hazards. Therefore, please ensure that any servicing of the speaker is done through the service provider or manufacturer.



- Please do not let the headphones come into contact with sharp edges, uneven surfaces, metal parts, accessories in a manner that can lead to some form of permanent external or internal damage.
- Please don't dismantle the product in any way, as this can lead to a fire or electrical breakdown and completely damage the product. As this is extremely unsafe, we ask that any maintenance of servicing of the headphones is done only through a qualified service provider/manufac-
- Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is
- Please clean the headphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please



