

成品90x90mm



User Manual


Thank you for choosing boAt Rockerz 205 Pro. This manual is meant to guide you through the functionality of the wireless earphone neckband. Knowledge of Bluetooth and device connection is essential for the usage of the headset. Therefore, we strongly advise that this manual is thoroughly read before use, and referred to in times of difficulty, so that you can always be easily guided towards the shores of musical bliss.

boAt
plug into nirvana

ROCKERZ 205 pro
Wireless Bluetooth Headsets

Package Contents

1. Rockerz 205 Pro x 1
2. User Manual x 1
3. Extra Earmuffs: S & L x 1
4. Type C Charging Cable x 1
5. Warranty Card x 1



Components

- | | |
|------------------------------------|-------------------------|
| 1. BEAST™ Mode Quick Switch Button | 4. Multifunction Button |
| 2. Volume down/Previous track | 5. Neckband |
| 3. Volume up/Next track | 6. LED Indicator |

Functions

- (1) Power on: When switched off, press and hold the MFB for 3 seconds. A voice prompt will confirm the same. The red and blue LEDs will flash to indicate the same.
- (2) Power off: In any mode, press and hold the MFB for 5 seconds. A voice prompt will confirm the same. The red LED will flash for 1 second before the device turns off.
- (3) Play/Pause: Single tap the MFB to play/pause music.
- (4) Volume up: Tap the volume "+" buttons in steps to increase the volume. A beep will indicate maximum volume.
- (5) Volume down: Tap the volume "-" button in steps to decrease the volume. A beep will indicate minimum volume.
- (6) Answer/End call: Tap the MFB once when answering or ending a call to complete the action.
- (7) Reject call: Press and hold the MFB for 2 seconds during an incoming call to reject the call
- (8) Previous Track: To go to the previous track, press and hold the "-" button for 2 seconds.
- (9) Next Track: To skip to the next track, press and hold the "+" button for 2 seconds.
- (10) Reset Device (Clear Paired List): Press and hold the "+" and "-" buttons simultaneously for 5 seconds to clear the previous list of connected devices. The red and blue LEDs will flash 3 times to indicate the same.
- (11) Dual Pairing: To connect Rockerz 205 Pro to two devices simultaneously, firstly connect the earphone to one of the devices. Then, switch both the earphone and the device off. Thereafter, connect the earphone to the second device, and again switch the first device on. The earphone will get connected to both devices. If not, connect the first device manually once again to activate dual pairing.
- (12) Voice Assistant: Long press the MFB for 2 seconds to wake up smart voice assistant
- (13) Redial: Triple tap the MFB for redialing the last contacted number
- (14) BEAST™ Mode: Single press the BEAST Mode quick switch button to activate low latency BEAST Mode. To turn it off, single press the same.
- (15) ENx™ Tech: Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mic is equipped with the same and activated by default.

Deliver your voice without interruptions anywhere – traffic, railway stations, airports, work space, literally anywhere!

To Pair with Bluetooth

- (1) When switched off, press and hold the MFB (*multifunction button) for 3 seconds to switch the earphones on. The earphone will automatically enter pairing mode with a prompt, the blue and red LEDs flash alternatively to indicate the same.
 - (2) Open Bluetooth on your device and search for "Rockerz 205 Pro" in the list of available devices.
 - (3) Choose "Rockerz 205 Pro" from the list and if asked enter the pairing password "0000" to establish Bluetooth connectivity.
 - (4) Once successfully connected, the blue LED flashes once every five seconds to indicate the same
- Note: The neckband automatically turns off if there is no pairing established in 5 minutes.

To Charge

Use a Type C charging cable to charge the earphone through either a laptop or an adaptor.

- (1) Low Battery: When the remaining talk time is less than 10 minutes, there is a 'low battery' prompt and red LED flashes quickly to indicate the same
- (2) Charging: Solid red LED indicates that the earphone is being charged (please note that the earphone cannot be turned on while charging).
- (3) Fully charged: Solid blue LED indicates the same.

Specifications

- | | |
|-----------------------------------|------------------------|
| • Bluetooth Version: | V5.0 |
| • Operating Range: | 10m |
| • Frequency: | 20Hz~20000Hz |
| • Driver Size: | 10mm*2 Drivers |
| • Battery: | 200mAh |
| • Talk time: | Up to 30 hours |
| • Music time: | Up to 30 hours |
| • Charging Time : | About 50 Min |
| • Charging Technology: | ASAP Charge Technology |
| • Driver Impedance : | 16Ω |
| • Dual Pairing: | Yes |
| • Water Resistance: | IPX5 |
| • Charging Port: | USB Type C |
| • BEAST™ Mode Latency: | 65ms |
| • ENx Tech (activated by default) | Yes |

Safety Cautions

- Please don't dismantle the product in any way, as this can lead to a fire or electrical breakdown and completely damage the product. As this is extremely unsafe, we ask that any maintenance or servicing of the earphones is done only through a qualified service provider/manufacturer.
- Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is strongly advised against.
- Please clean the earphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the earphones are kept away from extremely hot or cold substances.
- Any damage to the earphones that is NOT a manufacturing issue will make the products warranty null and void. Please take the greatest care of your earphones to ensure that no such occurrences take place.
- Do not use earphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing earphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens.
- To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are Plugging into Nirvana. After wearing the earphones, gradually turn up the volume until you reach a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing.

Dual Pairing:

To connect Rockerz 205 Pro to two devices simultaneously, firstly connect the earphone to one of the devices. Then, switch both the earphone and the device off. Thereafter, connect the earphone to the second device, and again switch the first device on. The earphone will get connected to both devices. If not, connect the first device manually once again to activate dual pairing.

Charging norms & Guidelines -

Charger/Adapter at 5V 2A and Standard Cable (25 strands @0.06mm diameter/strand)

CONNECT WITH US ON

- boAt-lifestyle.com
- facebook.com/boAtnirvana
- instagram.com/boAtnirvana
- youtube.com/boAt-nirvana

boAt
plug into nirvana

ROCKERZ 205 pro
Wireless Bluetooth Headsets

