




PRODUCT OVERVIEW



- 1. MFB button
- 2. Active Noise cancelling button
- Volume up
- 4. Volume down
- 5. Charging indicator6. USB-C charging port
- 7.3.5mm audio jack

Bluetooth version	V5.0
Bluetooth profiles	HSP/HFP/A2DP/AVRCP
Wireless range	10m(32ft)
Driver unit	40mm
Inpedance	32Ω+10%
Sound pressure level	103dB ±3dB
Frequency response	20Hz-20kHz
Battery capactity	Lithium battery3.7V 360mAh
Recharging input	DC 5V

SPECIFICATION

CHARGING

Please use the included USB-C cable to fully charge the headphones before first use.

The red LED will stay ON when charging, and the red LED will turn OFF when fully charged.

PAIRING

Pairing with one smartphone or other device.

Press and hold the MFB button for 3 seconds to turn headphones ON and enter into pairing mode.

The headphones red and blue lights flash. Turn Bluetooth ON in your device settings and select "BH MOKSHA" to connect.

NOTE: The headphones will automatically connect to your last connected device when switched ON, provided Bluetooth is ON and your device is within range.

MULTI FUNCTIONS

ТО	DO THIS
Play/Pause	Single press MFB
Previous Track	Long press V+
Next Track	Long press V-
Activate google/siri	Triple press MFB
Volume Up	Single press V+
Volume Down	Single press V-
ANC	Long press 2s
Answer a call	Single press MFB
End a call	Single press MFB
Reject a call	Dauble press MFB
Pairing	Red and blue lights flash alternately
Connected	Blue light blink slowly

USE YOUR HEADPHONES

- For the best sound and comfort, the right fit is very important. Please adjust your headband to make sure the headphones fit snugly and securely.
- Place your headphones on corresponding ear side
 ("R" on right ear and "L" on left ear).
- To ensure your headphones stay in place, make sure the cord is placed in front of our head and body.

PROTECTING YOUR HEADPHONES

- Use a soft cloth to clean headphones-DO NOT use any liquid.
- 2. Keep your headphones clean and free of debris
- DO NOT tug on the cable to disconnect the plug from your device, instead pull from the plug to disconnect.
- DO NOT wrap headphone around a device while it is still plugged in as it puts unnecessary pressure on the plug/ cord connection.

WARNING

- DO NOT insert plug into electric sockets.
- Listening to headphones at high volume levels, particularly over extended periods of time, may damage your hearing.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
- 4. The operation of switching on your Hi-Fi system or plugging in the headphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the headphones.
- 5. DO NOT use headphones while driving or cycling
- 6. Supervise children when using equipment. This product is not a toy.7. The small parts included with this product can be a choking
- hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.



Warranty Information 1 Year*

If you have issue with our ANC Bluetooth Headphone product please contact our service center Service Centre.

Authorized Service Center Blaupunkt Speakers Address: Envent World Wide Pvt Ltd. Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037 E-Mail: wecare@blaupunktaudio.in Tel. 18008434333

Please prepare & submit the following information during the telephone or e-mail notification to facilitate the process:

- -Serial Number
- -Date of purchase
- -A copy of proof of purchase in case of warranty

Note- Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.