

To completely enjoy using the boAt Stone Grenade, it is advised that this manual be read thoroughly for a complete understanding of the various functions. There are many features built into the boAt Stone Grenade and we want to do our utmost to help you hring it out for the perfect audionhile experience

Packaging contents

Micro USB cable-

Introduction


The boAt Stone Grenade is IPX6 water resistant indoor/outdoor wireless Bluetooth V5.0 Speaker with a Built-in Microphone. It supports most devices that are Bluetooth compatible. 5W Power output meant to give you complete audio bliss, get ready to Plug Into Nirvana.



Specifications:

- Bluetooth version: V5.0+EDR
- Output power: 5W
- Battery: 3.7V/1200mAh
- Speaker Unit: 4ohm/5W
- Frequency response: 70Hz~18KHz • Weight: 250g
- Size: 85mm x 55mm x 107mm Working time: Upto 7 hours of
- playback time.

 In built: Microphone
 Micro-USB port for connecting a
- ALIX in Jack Micro SD/TF Slot



boat



Buttons and functions

- 1. Press and hold the Power button "O" to power on and power off the

- 1. Press and note the "rower button" Or to power or and power or the speaker as per your requirement.

 2. Tap the Power button "O" when the speaker is switched on to change the mode between Bluetooth, Micro SO/TF, Aux-in mode.

 3. Tap the "D4" button to play/pause music at your convenience.

 4. Tap the "D4" button to answer any incoming calls on the connected device. Tap it again to end the call once finished.

 5. Press and hold the "—" button to reduce the volume to your preferred.
- 6. Press and hold the "+" button to increase the volume to your p
- 7. Tap the " " button to go back to the previous track.

 8. Tap the " + " button to skip to the next track.





kers are in pairing mode, a blue light will flash rapidly; once connected the blue light will blink but at a much slower pace.

When the speakers are in Micro SD/TF mode, the blue light will blink but at a much slower pace.

When in Aux-in mode, the blue light will blink but at a much slower pace.

To pair the Speaker

Bluetooth mode

1. Press and hold the "O" power button to switch the speakers on, there will be a prompt as well as the rapid blinking of the aforementioned LED indicator light. Turn on the Bluetooth function on your Smartphone.

2. Search for "boAt Stone Grenade " from the available list of

- Bluetooth devices and connect the two.

 3. Enter the passkey '0000' if one is asked for during
- 4. After successfully pairing, the speaker is now ready to play
- music from your Smartphone.

 5. The speaker will automatically connect to this device when switched on if it is in range and the Bluetooth mode is on.

Using the aux wire, plug one end of the 3.5 mm audio jack into the speakers and the other end into your Bluetooth device. A reminder tone will indicate that the connection is successful.



MICRO SD/TF Mode

Insert the Micro SD/TF Card into the slot to play music, the speakers can support files of an mp3/wma audio format with a maximum memory capacity of 32 GB. (Micro SD/TF card not included)

7. To Charge:

Use the Micro USB cable provided to charge the boAt Stone Grenade. Insert the micro cable end into the speaker and the USB port into a charging adapter or any other charging device.
 A red light will indicate the speakers have begun to charge. Depending on the charge; voltage and current, charging time can vary between 1-2 hours.
 Once charging has been completed, the LED light will switch off.

8. Additional Points

1. The boAt Stone Grenade is the perfect companion to take on a long journey Its portability allows for its usage in all kinds of moments. Spread the good vherever you go.

2. Attached with a woven carrying strap. You can conveniently carry this speaker along on a mountaineer's bag or on a cycle using the strap.

3. The boAt Stone Grenade comes with an inbuilt-mic and hands-free function for the most convenient of communication anywhere, anytime. If you need to clean the speaker, please turn off the speaker first and then gently wipe away any dirt with a soft damp cloth.



 Try to ensure that no physical damage comes to the speaker via falling, or coming into contact with hard surfaces or sharp edges.

 Do not dismantle the speaker or handle the battery in any way. If any issue arises with the speaker, please enlist the aid of a manufacturer. The battery must not be mishandled or replaced as when it can result in explosions or fire fizzards. Therefore, please ensure that any servicing of the speaker is done through the service provider or manufacturer.

While the speaker is IPX 6 water

Precaution

• Please note that the battery life of the speaker varies with the volume music is being played at. If at a lower volume, the battery life will be longer than when the speakers are playing at full volume.

• If the speaker requires cleaning, please ensure it is done with utmost care. Make sure the speaker is turned off and disconnected from all Bluetooth devices. Do not use alcohol, benzene and other chemicals to clean the speaker. Do not allow the speaker within range of extremely resistant, this does not mean that it is absolutely waterproof. Therefore, please ensure that the speaker is dried quickly and completely after coming into contact. Please do not allow the speaker to be submerged into water at all costs.

 To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are Plugging into Nirvana. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing. Therefore, listening sessions that are at higher volumes should not be for too long. If you are planning to use the speakers for extended periods of time, it is safer to keep the volume at a low level.

