



WELCOME

Thank you for purchasing the Stone 650 and welcome to the boAt family!

The Stone 650 is a unique portable audio system combining Bluetooth, Lithium ion battery & water-resistant technologies. The result is a rugged, shock resistant, water resistant, full range rechargeable wireless speaker system. Do everything from stream & play your music from your Bluetooth enabled smartphone or audio device, to answering your calls over the built-in speaker phone!

PACKAGE CONTAIN:


1. Bluetooth Speaker x 1 pc 2. Micro USB cable x 1 pc

4. User manual

x 1 pc

3. Aux in cable x 1 pc 5. Warranty card





FUNCTION PANEL:



Power ON/Power OFF

Volume Down

Play/Pause/BT disconnect/Hands free

KKI

Last Track

Next Track

BLUETOOTH MODE:

- 1. Press and hold to for up to 3 seconds turn the speaker ON/OFF. When in Bluetooth mode, the LED light will flash white rapidly. Make sure that Bluetooth is switched on in your mobile device and find "boAt Stone 650" from the list of available devices. Once connected, the white LED light will flash at a slower rate.
- 2. Use to decrease volume.
- 3. Use + to increase volume.
- 4. Use ⋈d to play the last track.
- 5. Use ⋈ to play the next track.
- 6. When there is an incoming call, press ≥ to answer it, and use the button to hang up once done.
- 7. Press and hold to reject an incoming call.
- 8. Press and hold № to disconnect from Bluetooth; Press № to Pause or Play media. When playing media, the White LED will flash slowly.
- 9. The speaker will power off if the Bluetooth connection is not activated within 2 minutes.

AUX IN MODE:

- 1. When powered on, connect the included Auxiliary cable into the port that is located at the back of the speaker and plug the other end into your phones auxiliary port.
- 2. Upon connection of the Aux, the speakers will automatically enter into Aux-in mode and play media from the connected mobile device; the Bluetooth light will be on and will not blink during this period.
- 3. When in Aux-in mode, Press & to switch to Bluetooth mode and vice
- 4. Press > to Pause or Play media.
- 5. The ⋈ button and ⋈ button cannot be used to change tracks in Aux-in mode, all music will have to be changed via the connected device. (Note: In "Aux-in" mode, the + button and the - button can be used to

adjust volume, please change the music by your device.)



SD/TF MODE:

The boAt Stone 650 is compatible with SD/TF cards, once inserted the speaker will turn into TF card mode and play automatically; the LED light flash slowly as an indicator.

- 1. Press > to Pause or Play media.
- 2. Press to decrease volume.
- 3. Press ⋈ to play the last track.
- 4. Press + to increase volume.
- 5. Press ≫to play the next track.
 6. When in SD/TF mode, Press ७ to switch to Bluetooth Mode and vice versa.

CHARGING:


The speaker comes with an inbuilt rechargeable battery. Before first use, please ensure that the battery is completely charged through the USB cable. While charging, the LED light next to the charging port will be red and it will turn off once full charged. It will take approximately 2-3 hours to reach full charge.



Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

FIRES AND ELECTRIC SHOCK HAZARD

- Do not expose your Stone 650 to extremely high or low temperatures.
- Do not leave your Stone 650 in direct sunlight for extended periods of time.
- Do not leave your Stone 650 near open flames such as cooking burners, candles, or
- Do not block any ventilation openings.



BATTERY/CHARGER HAZARD

- Do not dispose of your Stone 650 in a fire. The battery could explode causing
- Only charge the battery in accordance with the user instructions supplied with the Stone 650.
- Do not attempt to disassemble the Stone 650 charger or force open the built-in battery because this may result in electric shock.
- Do not clean the Stone 650 when it is being charged. Always unplug the charger first before cleaning the Stone 650.

AUTOMOBILE ACCIDENT HAZARD

Do not leave or store the Stone 650 or any of its accessories near or over your automobile's air bag because serious injury may result when an air bag

FURTHER CAUTIONS:

- Do not use abrasive cleaners to clean your Stone 650 because this could cause scratches and damage.
- Do not bring your Stone 650 in to contact with any sharp objects because this could cause scratches and damage.
- Do not insert anything into your Stone 650 unless otherwise specified in the user instructions. This may damage the internal components.
 Do not attempt to repair, modify, or disassemble your Stone 650 yourself, it does not
- Contain any user-serviceable components.

 Do not attempt to replace your Stone 650 battery, it is built-in and is not changeable.
- Turn off your Stone 650 prior to boarding an aircraft. Do not use Stone 650 inside an
- Time of your active 300 print to boarding an arctart. But not use 3 tone 300 inside an aircraft unless allowed by your airline.
 Dispose of the Stone 650 or the Stone 650's battery in accordance with local regulations. Do not dispose of the battery with regular household waste.



facebook.com/boat.nirvana



instagram.com/boat.nirvana



twitter.com/BoatNirvana

youtube.com/boatnirvana



