

User Manual

Thank you for purchasing the boAt Stone 300. You are now just a step away from the Realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology and aux wire compatibility. This portable speaker has been designed for smooth interface that requires the most minimal of efforts. It's time to Plug Into Nirvana.


Package Contents:

- 1 x boAt Stone 300 speaker
- 1x Micro-USB Cable
- 1 x AUX Cable (03.5mm)
- 1x User Manual



STONE
Bluetooth Speaker 300

Product Diagram :



Power On:

Press the **⏻** button until you hear a beeping sound and the LED indicator light comes on.

Power Off:

Press the **⏻** button until you hear a beeping sound and the LED indicator light goes off.

Functions

- Play / Pause Click **⏻**
- Volume Up Click **+**
- Volume Down Click **-**
- Next track Press and Hold **+**

- Previous track Press and Hold **-**
- Switch Bluetooth mode/Aux-in mode Click **⏻**
- Answer an incoming call Click **⏻**
- Reject an incoming call Press and Hold **⏻**
- End the current call Click **⏻**
- Redial last-called number Press and Hold **⏻**

To Pair Bluetooth :

1. Press the **⏻** button until you hear a beeping sound and the LED indicator light comes on. The LED light will start flashing blue rapidly as it enters Bluetooth mode.
2. Make sure that the speaker is within 10 meters of your Bluetooth device.
3. Go to the Bluetooth settings on your device, search and select "boAt Stone 300" from the list of options.
4. Once successfully paired, the LED indicator turns solid blue.

Note:

• When powered on, the speaker automatically reconnects to the last device it was connected to. (The speaker can memorize maximum of 8 paired devices).

• The speaker will automatically shut down to save power if after 10 minutes, it has not been paired.

• Please note that play time will vary depending on the selected volume level.

Disconnect Bluetooth

Press the **+**, **-** buttons simultaneously until you hear a beep and the LED Indicator light is rapidly flashing blue to disconnect the currently connected device.

Aux Mode

1. Press the **⏻** button until you hear a beeping sound and the LED indicator light comes on.
2. Insert the AUX Cable (ø3.5mm) into the Aux port on the speaker and on the external device.
3. The speaker will automatically turn to AUX-in mode; and the LED Indicator light will turn solid green.

Note: In AUX-IN mode, changing songs and hands-free communication is not available.

boat
plug into nirvana

**BATTLE THE
ELEMENTS**



STONE
Bluetooth Speaker 300

Kartik Aaryan
Kartik Aaryan

To Charge

- (1) Use a micro USB charging cable to charge the speakers; it is recommended that the speakers are fully charged before first time use.
- (2) Connect the Micro-USB Cable (included) between the **DC IN** port on the speaker, and a USB port on a computer or USB AC Adapter.
- (3) Charging: The red light is on and not blinking.
- (4) Fully charged: The Red light will go off.
- (5) It is recommended that the speakers are not used while they are being charged, as it is not good for the battery.

Note: When the battery charge <3%, the speaker will power off automatically.

Specifications :

- Bluetooth 5.0
- Transmission distance: 10M
- Material: ABS+ Metal
- Rated Power: 4W
- Driver Unit: ø50 mm(4 Ω, 5W)
- Frequency response: 180Hz-20kHz
- Signal-to-noise ratio: >80dB
- Battery: 3.7V/1500MAH
- DC input voltage/current: 5V/0.5A
- Playtime: 4-10hours
- Battery charge time: 3-4hours
- Dimensions: 87*83.5*45 mm
- Weight: 210g
- Water Resistance: IPX 7

Cautions:

- Please note that the battery life of the speaker varies with the volume music is being played at.
- If at a lower volume, the battery life will be longer than when the speakers are playing at full volume.
- If the speaker requires cleaning please ensure that it is done with the utmost of care. Further, make sure it is turned off and disconnected from all Bluetooth devices.

- Do not use alcohol, benzene and other chemicals to clean the speaker.
- Do not allow the speaker within range of extremely hot or cold substances.
- Try to ensure that no physical damage comes to the speaker via falling, or coming into contact with hard surfaces or sharp edges.
- Do not dismantle the speaker in any way. If any issue arises with the speaker, please enlist the aid of a manufacturer.
- The battery must not be mishandled or replaced as when it can result in explosions or fire hazards. Therefore, please ensure that any servicing of the speaker is done through the service provider or manufacturer.

Troubleshooting:

1. Cannot Power On:
 - Charge the headphone and make sure it has enough battery charge.
2. Trouble connecting with device:
 - Please check the follows:
 - The Bluetooth device supports A2DP profile
 - The Speaker is within 10m from the device.
 - The Speaker is in pairing mode, the LED indicator blinking blue and blue
3. No Sound:
 - Make sure the music volume is at audible level on both your device and speaker.
 - Make sure your device is successfully paired with the headphone, the LED indicator turn solid blue.
4. Poor sound quality:
 - Move the device closer to this Speaker or remove any obstacle between them.