

**BELIEVE
IN YOUR
SENSES**



Airdopes 391
True Wireless Ear-buds

boat

Get ready to immerse yourself in musical bliss with your very own pair of boat Airdopes 391. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss.

Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.



PACKAGE CONTENTS

- 1x Pair of Ear-buds
- 2x Pairs of Additional Earmuffs
- 1x Type C Cable
- 1x Catalogue
- 1x Charging Case
- 1x User Manual
- 1x Warranty Card

Power On (First Time Usage)

Step 1: To automatically search the headset in Smart Power On simply take out the earbuds from the carry case starting from the right earbud and then the left earbud. The left earbud flashes rapidly and the right earbud flashes slowly for every 5-8 seconds (right earbud is the Master earbud).

OR

To manually switch the earbuds on (Manual Power On), long touch the Capacitive touch control (CTC) for 5 seconds on both Right and Left earbuds until the LED begins to flash in red and blue.

Step 2: Both the earbuds automatically enter into the Connection Mode.

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for Airdopes 391 and tap on the same for pairing. For most cases, the right earbud gets paired instantly and then it goes to window for pairing the left earbud may come up on the screen with the name Airdopes 391. Tap on the same to proceed with the pairing process.



Congratulations! Your earbuds are now connected successfully via Bluetooth.

Power On (Subsequent Usage)

The next time when you open the lid of the case, our IWP™ (Instant Wake n Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

Note

- Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above-mentioned procedure.
- Airdopes 391 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices.



Single Earbud Usage

- Step 1:** Please note that both the earbuds can be used in mono mode. Use either of the two options: Smart Power On or Manual Power On for switching on the desired earbud.
- Step 2:** The selected earbud will automatically enter the connection mode indicated by red and blue LED flashes.
- Step 3:** Turn on Bluetooth on your phone/media device and search for Airdopes 391 / Airdopes 391 L to connect.



Note

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.
- If you keep the right earbud inside the case (applies for the left earbud also) during stereo mode, the left (or right) earbud can be used in mono mode but the transition might take 2-3 seconds.

LED Indicators / Functionalities

- 2 Seconds** Long touch the CTC (Capacitive Touch Control) for 2 sec on either earbud to activate voice assistant / reject incoming calls.
- 3 Seconds** Long touch the CTC for 3 sec to manually Power On.
- 5 Seconds** Long touch the CTC for 5 sec to manually Power Off.
- Triple Tap** Triple tap the CTC on both earbuds for Factory Reset indicated by blue and red LED flashes.



Charging The Earbuds

- Step 1:** Please insert the earbuds back inside the charging case in correct orientation.
- Step 2:** A solid red LED will indicate that the earbuds are being charged. Once fully charged the LED turns off.
- Step 3:** Once the earbuds are fully charged, the charging case automatically switches off to save power.

Note

- Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging.
- When the earbuds are in low power, flashing red LED indicates the same.



Charging The Case

Step: Use the USB Type C cable to charge the case. The charging gets indicated by red LED on charging case. Once fully charged the LED turns off.

Remaining Battery LED Indicator—Displays while one opens the case.

Status	LED Indicator
Remaining battery 0%-30%	White LED blinks once when case opened
Remaining battery 30% - 66%	White LED blinks twice when case opened
Remaining battery above 66%	White LED blinks thrice when case opened

Note: The LED lights located on the charging case indicate the battery status of the case.

Basic Functions

- **Voice Assistant:** Long touch the CTC on either earbud for 2 seconds to activate the voice assistant.
- **Answer/Hang Up Call:** Single tap the CTC on either earbud to answer an incoming call and once again to hang up an ongoing call.
- **Repeat Call:** Long touch the CTC for 2 seconds to reject incoming calls.
- **Play/Pause Music:** Single tap the CTC on either earbud to play or pause a song.
- **Next Track:** When playing music, double tap the right CTC to skip to the next song.
- **Previous Track:** When playing music, double tap the left CTC to return to the previous song.


Note: Volume cannot be controlled via earbuds and can only be adjusted via phone/media device.

Voice Assistant

- Step 1:** Long touch the CTC on either earbud for 2 seconds to activate the smart voice assistant.
- Step 2:** The respective voice assistant screen pops up and you may place your commands at ease.

Tip: You may try out the following commands

- What is the weather?
- Play a song
- Set a reminder



Smart Power Off

- Step 1:** After usage, remove both the earbuds from your ears.
- Step 2:** Place the earbuds back into the charging case in correct orientation.
- Step 3:** The earbuds will automatically switch off (and enter into charging mode).

Manual Power Off

- Case 1:** Long touch the CTC on the right earbud for 5 seconds, in order to manually switch off the earbuds. Please note that this powers off both the earbuds (Case 1 earbud is the master earbud).
- Case 2:** Initially if you long touch the CTC on the left earbud for 5 seconds, then only the left earbud gets turned off and then the above process has to be repeated for turning off the right earbud as well.

Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 391. (Clear all pairing list records from your media device by choosing "forget device" before performing factory reset).

- Step 1:** Place the earbuds inside the case and close the lid.
- Step 2:** Take out the earbuds from the case, wait for them to power on and triple tap the CTC on both of them, red and blue LED flashes thrice.
- Step 3:** Place the earbuds back inside the case and close the lid.
- Step 4:** As soon as you open the lid of the carry case, the earbuds power on and the factory reset gets completed.

Congratulations! Your Airdopes 391 has been Reset.

Common Problems with Solutions

If only one earbud is functioning:

Simply insert the earbuds back into the case and take them out or perform the Factory Reset.

If earbuds are not in scan mode:

Simply insert the earbuds back into the case and take them out or perform the Factory Reset.

Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
Touch Controls don't seem to respond	After long usage, residual stains and perspiration can affect the touch control area, please use a clean cloth to wipe those areas softly

Charging mode & Precautionary Guidelines:

1) Charging/Block Adapter	1) 5V 2A
2) Cable/Type	2) Standard Cable (33 strands 85 Tinned diameter) standard

Any other accessory cable be paired up with the product as long as the specifications are as per above norms.

Specifications

Bluetooth Version	V5.0
Water Resistance	IPX4
IWP Technology	Yes
Music Playtime	Up to 4.5H per Charge, Up to 18H Additional with Case
Battery	45mAh *2 earbuds, 400mAh case
Transmission Range	10m
Driver Size	26mm
Bluetooth Profile	HFP, HSP, A2DP, AVRCP
Frequency	2012-20412
Chip Operation	Qualcomm
Audio Technology	Qualcomm aptX™
Charging Technology	ASAP Charge Technology
Call Noise Reduction	Qualcomm cVOC™
Charging Time	About 40 minutes
Call Noise Isolation	Type C
Product Weight	Earbuds: 4.4g*2, Total 47.9g

Warning

- Please follow the instructions to operate.
 - Please don't use the ear-buds in extreme temperatures.
 - Please don't use the product in water.
 - Please keep the product away from heat sources, as the heat may damage it.
 - Don't use the product with a charger panel, LED panel, etc.
 - It is recommended to use the product below the maximum volume in order to protect hearing and extend the ear-buds service life.
- Advisable:** The earbuds start at a 100% volume and it may need to be reduced when the earbuds are used for the first time. This can be done by using the volume control on the phone/media device.