

Instruction Manual



Enjoy it.

EM-10

WIRED EARPHONE

TECHNOLOGY SPECIFICATION
Speaker size: 10mm
Sensitivity: 108±3dB
Impedance: 16 Ω

BLAUPUNKT

Frequency response : 20 ~ 20000Hz Cable length : 120cm Plug Pin : 3.5mm

PRODUCT DESCRIPTION Standard 3.5mm plug pin, EM-10 can use in most of

EM-10

portable broadcast equipments, such as smart cellphone, ipad, laptop, MP3 or professional audio player, etc. Provide you several models backup earcap help you select the most comfortable way to listen music. ABS plastic ear conch and the lightweight appearance make it comfortable to wear! The design of wire control turning

makes no influence for listen to music and phoning. The

slipping and locking cable design can bring a enjoyable experience to you.

CAUTION

1) Don't wear at a high volume for a long time. Avoid

dust, moisture and stains.
2) Handle with care, don't contact high temperature and sharp objects to avoid damaging the structure and function of product.

EM-10

answer calls)

Note the difference between the right(R) and left(L) earphones and insert earphone into each ear.

earphones and insert earphone into each ear.


2) Caption:

1. Pause/Play (short press button 1 time)

Previous Music (continuous short press button 3 times)
 Next Music (continuous short press button 2 times)

Answer Calls (short press button 1 time)
 Hang Up Calls (short press button 1 time after

Reject Calls (long press button about 1 second)



EM-10

Balapunkt

Thank you for purchasing our EM-10 Wired Earphone. Please read the instruction carefully before using it, in order to know the proper operations of the product.

WARRANTY INFORMATION 1 YEAR*

If you have issue with EM-10 product please contact our service center.

Authorized Service Center Blaupunkt Speakers Address: Enwent World Wide Pvt. Ltd., Khasra No- 15/15 (4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi-110037.

E-Mail: wecare@blaupunkt-audio.in | Tel: 1800 843 4333

Please prepare and submit the following information during the telephone or e-mail notification to facilitate the process:

- Serial number

- A copy of proof of purchase in case of warranty

Note - Important information:

- Date of purchase

Note - Important information:
Please use the original packaging or other suitable packaging to protect the unit in transit.